



SWISS TACKLE

Markus Rohrbach, Speichergasse 4, CH-3150 Schwarzenburg
www.swisstackle.com / sales@swisstackle.com

WARRANTY

The warranty is one year for material and manufacturing deficiencies. Any rejected devices must be returned to us and – provided that the defect is indeed covered by the guarantee, it will be repaired or replaced free of charge. The customer cannot claim any warranty rights if the product is not registered immediately after purchasing, or damages have been caused by inappropriate handling or a lack of maintenance of the product.

Please register your product at: www.swisstackle.com

MAINTENANCE

To make sure that the tackle is always in perfect working order, it is important that it be kept clean at all times. This requirement applies especially to the running surfaces of the reel bearings. Should the reel not be in a position to turn without hindrance, rinse the tackle thoroughly with clean water. The wet tackle should not be kept in the tackle bag for a prolonged period. Once a year, all the screws need to be checked with regard to their tight fitting.

SPAREPARTS

For spare part orders please specify always serial number of the reel and desired part number.

